



Repairing RIM Blackberry 8700c New Keypad

Tools used in this guide


- [Metal Spudger](#)
- [T6 Torx Screwdriver](#)



Step 1 - New Keypad

- After removing battery cover and battery, you now need to remove the back cover of the phone.
 - To do this unscrew all four T6 screws
 - Once this is done gently remove the back cover of the phone by pulling first from the bottom towards you, then from the top upwards.






Step 2


- You will now see the inner back cover of the phone.
 - To remove unscrew the 4 T6 screws
- Once this is done, carefully lift the cover off of the phone. (a small side piece will fall away as well.)



Step 3


- Once the final 4 screws are removed, you now have access to separate the logic board and from the front cover.
 - To do this, gently lift the logic board from the front cover.





Step 4

- While firmly holding the logic board, use a metal spudger to unclip the four clips holding the screen on.
 - Now gently pull the screen slightly away from the logic board so that none of the clips are engaged on the board.
- Last, use the metal spudger to push back the ribbon cable lock.



Step 5

- The screen is now completely removed and can be replaced.

